


Model:	
	AWI-54HRDC1TB
	Wiring Diagram



! WARNING

Please don't touch any terminal when the machine is running, stopping or has been powered off for less than 30 minutes to prevent the risk of electric shock!



Model:	
	AWO-54HRDC1C
	Wiring Diagram

